


Technical Details



DFM 36MX297-ML



Table of Contents



1.	Quick Facts 3					
2.	Electrical Characteristics	5				
2.	1 Absolute Maximum Ratings	5				
2.	2 Recommended Operating Conditions	5				
3.	Dimensional Diagrams	6				
3.	1 DFM 36MX297-ML Board Camera	6				
4.	Spectral Characteristics	7				
4.	1 Spectral Sensitivity - IMX297LQR-C	7				
5.	Connector Description	8				
6.	CSI Lane Configurations 11					
7.	I2C Devices 12					
8.	Programming the Image Sensor	13				
8.	1 Input Clock	13				
8.	2 Power-up Sequence	13				
8.	3 Further Assistance					



1 Quick Facts

General				
Dynamic Range	10 bit			
Resolution	720x540			
Frame Rate at Full Resolution	120			
Pixel Formats	10-Bit Bayer (RG)			

Optical Interface				
Sensor Type	Sony IMX297LQR-C			
Shutter Type	Global			
Sensor Format	1/2.9 inch			
Pixel Size	6.9 µm			

Electrical Interface

Interface	The Imaging Source MIPI CSI-2 Sensor Board Connector
Number of active CSI lanes	1
Supply voltage	5V (±10%)
Current consumption	approx 185 mA @ 5 VDC

Mechanical Data	
Dimensions	H: 30 mm, W: 30 mm, L: 5.45 mm
Mass	4 g

Adjustments	
Shutter	1 µs to 1 s
Gain	0 dB to 48 dB

Quick Facts



Environ	mental

Temperature (operating)

Temperature (storage)

Humidity (operating)

Humidity (storage)

-5 °C to 45 °C -20 °C to 60 °C 20 % to 80 % (non-condensing) 20 % to 95 % (non-condensing)



2 Electrical Characteristics

2.1 Absolute Maximum Ratings


Item	Symbol	Pins	Min	Max	Unit
Supply voltage	V_IN	+5V_VDD	-0.3	+6.0	V
I/O voltage	V_IO	CAM_PWR RESET CLK STROBE TRIGGER	-0.3	+2.1	V
I2C voltage	V_12C	I2C_SCL I2C_SDA	-0.3	+2.1	V

2.2 Recommended Operating Conditions

Item	Symbol	Pins	Min	Тур	Max	Unit
Supply voltage	V_IN	+5V_VDD	4.5	5.0	5.5	V
I/O voltage	V_IO	CAM_PWR RESET CLK STROBE TRIGGER	1.7	1.8	1.9	V
I2C voltage	V_12C	I2C_SCL I2C_SDA	1.7	1.8	1.9	V



- **3** Dimensional Diagrams
- 3.1 DFM 36MX297-ML Board Camera




Tolerances: DIN ISO 2768-m 289-20-0-02-00



4 Spectral Characteristics


4.1 Spectral Sensitivity - IMX297LQR-C





5 Connector Description

The DFM 36MX297-ML sensor board is connected to the system via the *The Imaging Source MIPI CSI-2 Sensor Board Connector.*





1GNDGNDGround2-NC-3-NC-4GNDGNDGround5MIPI_CH1_NOMIPI CSI-2 output6MIPI_CH1_POMIPI CSI-2 output7GNDGNDGround8MIPI_DCK_NOMIPI CSI-2 output9MIPI_DCK_POMIPI CSI-2 clock10GNDGNDGND11-NC-12-NC-13GNDGNDGround14-NC-15-NC-16GNDGNDGround17GNDGNDGround18GNDGNDGround19ICANC-10GNDGNDGround11-NC-12GNDGNDGround13GNDGNDGround14-NC-15-NC-16GNDGNDGround17CLKINSererec clock input (with 1k pull-down/termination resistor on sensor board)19I2C_SCLI/OI2C serial clock10I2C serial clockI11SESERVED_1ID on tu se12RESERVED_2ID on tu se13SROBEID on tu se14STROBEINC15<	#	Name	Туре	Description
3-NC4GNDGNDGround5MIPI_CH1_NOMIPI CSI-2 output6MIPI_CH1_POMIPI CSI-2 output7GNDGNDGround8MIPI_DCK_NOMIPI CSI-2 clock9MIPI_DCK_POMIPI CSI-2 clock10GNDGNDGround11-NC	1	GND	GND	Ground
4GNDGNDGNDGround5MIPI_CH1_NOMIPI CSI-2 output6MIPI_CH1_POMIPI CSI-2 output7GNDGNDGround8MIPI_DCK_NOMIPI CSI-2 clock9MIPI_DCK_POMIPI CSI-2 clock10GNDGNDGround11-NC	2	-	NC	
5MIPI_CH1_NOMIPI CSI-2 output6MIPI_CH1_POMIPI CSI-2 output7GNDGNDGround8MIPI_DCK_NOMIPI CSI-2 clock9MIPI_DCK_POMIPI CSI-2 clock10GNDGNDGround11-NC	3	-	NC	
6MIPL CH1_POMIPI CSI-2 output7GNDGNDGround8MIPI_DCK_NOMIPI CSI-2 clock9MIPI_DCK_POMIPI CSI-2 clock10GNDGNDGround11-NC	4	GND	GND	Ground
7GNDGNDGNDGround8MIPI_DCK_NOMIPI CSI-2 clock9MIPI_DCK_POMIPI CSI-2 clock10GNDGNDGround11-NC	5	MIPI_CH1_N	0	MIPI CSI-2 output
8MIPI_DCK_NOMIPI CSI-2 clock9MIPI_DCK_POMIPI CSI-2 clock10GNDGNDGround11-NC-12-NC-13GNDGNDGround14-NC-15-NC-16GNDGNDGround17CLKNC-18CAM_PWRIReference clock input (with 1k pull-down/termination resistor on sensor board)19I2C_SCLI/OI2C serial clock20I2C_SDAI/OI2C serial data21RESERVED_1IDo not use22RESERVED_2IDo not use23RESERVED_2IDo not use24STROBEOStrobe output25TRIGGERITigger input (weak pulldown on sensor board)	6	MIPI_CH1_P	0	MIPI CSI-2 output
9MIPI_DCK_POMIPI CSI-2 clock10GNDGNDGround11-NC-12-NC-13GNDGNDGround14-NC-15-NC-16GNDGNDGround17CLKNC-18CAM_PWRIReference clock input (with 1k pull-down/termination resistor on sensor board)19I2C_SCLI/OI2C serial clock20I2C_SDAI/OI2C serial clock21RESERVED_1IDo not use22RESETIDo not use23RESERVED_2IDo not use24STROBEOStrobe output25TRIGGERITigger input (weak pulldown on sensor board)	7	GND	GND	Ground
10GNDGNDGround11-NC-12-NC-13GNDGNDGround14-NC-15-NC-16GNDGNDGround17CLKGNDGround18CAM_PWRIGround1912C_SCLI/OI2C serial clock input (with 1k pull-down/termination resistor on sensor board)19I2C_SDAI/OI2C serial clock20RESERVED_1IDo not use21RESERVED_2IDo not use22STROBEOStrobe output24STROBEOStrobe output	8	MIPI_DCK_N	0	MIPI CSI-2 clock
11-NCImage: NC12-NC-13GNDGNDGround14-NC-15-NC-16GNDGNDGround17CLKGNDGround18CAM_PWRIReference clock input (with 1k pull-down/termination resistor on sensor board)19I2C_SCLI/OI2C serial clock20I2C_SDAI/OI2C serial clock21RESERVED_1IDo not use22RESETIDo not use23RESERVED_2IDo not use24STROBEOStrobe output25TRIGGERITigger input (weak pulldown on sensor board)	9	MIPI_DCK_P	0	MIPI CSI-2 clock
12-NCReparation of the second	10	GND	GND	Ground
13GNDGNDGNDGround14-NC-15-NC-16GNDGNDGround17CLKINReference clock input (with 1k pull-down/termination resistor on sensor board)18CAM_PWRIHigh active camera power enable signal (10k pull-down on sensor board)19I2C_SCLI/OI2C serial clock20I2C_SDAI/OI2C serial data21RESERVED_1IDo not use22RESETIDo not use23RESERVED_2IDo not use24STROBEOStrobe output25TRIGGERITigger input (weak pulldown on sensor board)	11	-	NC	
14-NC15-NC16GNDGNDGround17CLKIReference clock input (with 1k pull-down/termination resistor on sensor board)18CAM_PWRIHigh active camera power enable signal (10k pull-down on sensor board)19I2C_SCLI/OI2C serial clock20I2C_SDAI/OI2C serial data21RESERVED_1IDo not use22RESETIDo not use23RESERVED_2IDo not use24STROBEOStrobe output25TRIGGERITrigger input (weak pulldown on sensor board)	12	-	NC	
15-NC16GNDGNDGround17CLKIReference clock input (with 1k pull-down/termination resistor on sensor board)18CAM_PWRIHigh active camera power enable signal (10k pull-down on sensor board)19I2C_SCLI/OI2C serial clock20I2C_SDAI/OI2C serial data21RESERVED_1IDo not use22RESETIDo not use23RESERVED_2IDo not use24STROBEOStrobe output25TRIGGERITrigger input (weak pulldown on sensor board)	13	GND	GND	Ground
16GNDGNDGround17CLKIReference clock input (with 1k pull-down/termination resistor on sensor board)18CAM_PWRIHigh active camera power enable signal (10k pull-down on sensor board)19I2C_SCLI/OI2C serial clock20I2C_SDAI/OI2C serial data21RESERVED_1IDo not use22RESETIDo not use23RESERVED_2IDo not use24STROBEOStrobe output25TRIGGERITrigger input (weak pulldown on sensor board)	14	-	NC	
17CLKIReference clock input (with 1k pull-down/termination resistor on sensor board)18CAM_PWRIHigh active camera power enable signal (10k pull-down on sensor board)19I2C_SCLI/OI2C serial clock20I2C_SDAI/OI2C serial data21RESERVED_1IDo not use22RESETIReset sensor to default state when low (2.2k pull-down on sensor board)23RESERVED_2IDo not use24STROBEOStrobe output25TRIGGERITrigger input (weak pulldown on sensor board)	15	-	NC	
Image: select of the select	16	GND	GND	Ground
Image: Sensor board19I2C_SCLI/OI2C serial clock20I2C_SDAI/OI2C serial data21RESERVED_1IDo not use22RESETIReset sensor to default state when low (2.2k pull-down on sensor board)23RESERVED_2IDo not use24STROBEOStrobe output25TRIGGERITrigger input (weak pulldown on sensor board)	17	CLK	Ι	
20I2C_SDAI/OI2C serial data21RESERVED_1IDo not use22RESETIReset sensor to default state when low (2.2k pull-down on sensor board)23RESERVED_2IDo not use24STROBEOStrobe output25TRIGGERITrigger input (weak pulldown on sensor board)	18	CAM_PWR	I	
21RESERVED_1IDo not use22RESETIReset sensor to default state when low (2.2k pull-down on sensor board)23RESERVED_2IDo not use24STROBEOStrobe output25TRIGGERITrigger input (weak pulldown on sensor board)	19	I2C_SCL	I/O	I2C serial clock
22RESETIReset sensor to default state when low (2.2k pull-down on sensor board)23RESERVED_2IDo not use24STROBEOStrobe output25TRIGGERITrigger input (weak pulldown on sensor board)	20	I2C_SDA	I/O	I2C serial data
Image: Sensor board23RESERVED_2I24STROBEO25TRIGGERI	21	RESERVED_1	1	Do not use
24 STROBE O Strobe output 25 TRIGGER I Trigger input (weak pulldown on sensor board)	22	RESET	I	
25 TRIGGER I Trigger input (weak pulldown on sensor board)	23	RESERVED_2	1	Do not use
	24	STROBE	0	Strobe output
	25	TRIGGER	1	Trigger input (weak pulldown on sensor board)
20 +5V_VUU PWK 5V (±10%) power supply	26	+5V_VDD	PWR	5V (±10%) power supply
27 +5V_VDD PWR 5V (±10%) power supply	27	+5V_VDD	PWR	5V (±10%) power supply
28 GND GND Ground	28	GND	GND	Ground



All I/Os have the same I/O voltage of 1.8V. The manufacturer part number of the Hirose connector is FH28D-28S-0.5SH(98).



6 CSI Lane Configurations

The following table shows the relationship between used CSI lanes and maximum frame rate:

No of CSI Lanes	Bits Per Pixel	Maximum Frame Rate at Full Resolution
1	10	120



7 I2C Devices

There are multiple I2C devices on the DFM 36MX297-ML sensor board. The following table describes the parts and their I2C addresses:

Address (7-bit)	Device	Description
0x1A	IMX297LQR-C	Image Sensor
0x50	AT24C256C	EEPROM
0x57	AT24C02C	EEPROM



8 Programming the Image Sensor

The data sheet for the IMX297LQR-C image sensor is not publicly available.

8.1 Input Clock

The CLK pin has to be connected to a clock source. The following table lists the ranges of clock frequencies that are supported by the image sensor:

Minimum	Typical	Maximum	Unit
35.64	37.125	37.867	Hz
51.84	54	55.08	Hz
71.28	74.25	75.735	Hz

The driver provided by The Imaging Source assumes a CLK frequency of **37 MHz**. For quick integration with existing software, using this frequency is recommended.

8.2 Power-up Sequence

Delay	Action
-	Set RESET to Hi-Z
-	Set CAM_PWR to Hi-Z
-	Supply 5V to 5V_VDD
-	Supply sensor clock to CLK
1 µs	Set CAM_PWR to high
20 µs	Set RESET to high
11 ms	Write sensor registers

8.3 Further Assistance

For more detailed information, register settings and assistance integrating the sensor board into your product, please contact The Imaging Source support.



DFM 36MX297-ML

All product and company names in this document may be trademarks and tradenames of their respective owners and are hereby acknowledged.

The Imaging Source Europe GmbH cannot and does not take any responsibility or liability for any information contained in this document. The source code presented in this document is exclusively used for didactic purposes. The Imaging Source Europe GmbH does not assume any kind of warranty expressed or implied, resulting from the use of the content of this document or the source code.

The Imaging Source Europe GmbH reserves the right to make changes in specifications, function or design at any time and without prior notice.

Last update: September 2021

© 2021 The Imaging Source Europe GmbH

All rights reserved. No part of this publication may be reproduced, distributed, or transmitted in any form or by any means, including photocopying, recording, or other electronic or mechanical methods, without the prior written permission of the publisher, except in the case of brief quotations embodied in critical reviews and certain other noncommercial uses permitted by copyright law.

All weights and dimensions are approximate. Unless otherwise specified, the lenses shown in the context of cameras are not shipped with these cameras.

Headquarters:

The Imaging Source Europe GmbH Überseetor 18, D-28217 Bremen, Germany Phone: +49 421 33591-0

North & South America:

The Imaging Source, LLC 6926 Shannon Willow Rd, S 400, Charlotte, NC 28226, USA Phone: +1 704-370-0110

Asia Pacific:

The Imaging Source Asia Co., Ltd. 2F., No.8, Xinhu 1st Road Taipei City 114, Neihu District, Taiwan Phone: +886 2-2792-3153

www.theimagingsource.com